



Decks

© Insurance Institute for Business & Home Safety

© Insurance Institute for Business & Home Safety

© Insurance Institute for Business & Home Safety

Reduce the Vulnerability of Your Deck to Wildfire

MANY HOMES LOCATED IN WILDFIRE-PRONE AREAS HAVE ATTACHED DECKS, WHICH CAN POTENTIALLY SPREAD FIRE TO THE HOUSE WHEN IGNITED DURING A WILDFIRE.

A burning deck can ignite siding or break the glass in doors or windows, allowing fire to gain entry into the house. Consequently, making decks less vulnerable to wildfire also makes your house less vulnerable. Reducing the deck's vulnerability requires an approach that focuses on the materials and design features used to build the deck, and creating a noncombustible zone around and under the deck.

EMBER EXPOSURE AND IGNITION

Walking surfaces of decks are either solid surface or constructed using deck boards (with between board gaps). Solid surface decks are commonly light weight concrete or tile. Combustible deck board types include: solid wood and wood-plastic composites (these products are more widely used than noncombustible deck boards). Noncombustible deck board types include: metal and fiber cement.

Recent testing at the IBHS Research Center showed embers mostly lodge between deck board gaps and where deck boards rest on joists. Embers can accumulate and potentially ignite decking and combustible joists. Embers can also fall through board gaps and land on materials stored beneath the deck. It's critical to remove all combustible materials from the under-deck area to minimize the opportunity for ignitions; where resulting flames would impinge on the decking (some wood-plastic decking products are vulnerable to flaming exposures).

IBHS tests also showed that even without vegetative debris in between deck gaps, medium density softwood decking products, such as redwood or western redcedar are vulnerable to ember ignitions. Most wood-plastic composites, along with higher density tropical hardwood, and fire-retardant treated decking products are less vulnerable to embers. The vulnerability to embers in these locations is a reminder to remove debris that accumulates in these areas.

BUILDING CODE REQUIREMENTS

The International Wildland Urban Interface Building Code (IWUIC) and the California Building Code are the most commonly referenced construction codes for wildfire-prone areas; both include requirements that focus on the walking surfaces of decks. Noncombustible products are allowed by both codes.

The California Code provides provisions for accepting combustible decking products. These types of products are more commonly used by homeowners living in wildfire-prone areas across the country. Their requirement governs the amount of heat released when

combustible decking is ignited by a gas burner. This mimics burning debris that could be located under the deck, or burning vegetation impinging on the underside of the deck, but does not mimic ember exposure. Combustible decking products that comply with the California Code can be found at: http://osfm.fire.ca.gov/licensinglistings/licenselisting_bml_searchcotest.

The IWUIC prohibits common combustible deck boards with the exception of fire-retardant treated decking (rated for outdoor exposure) and other materials

- Photo Captions:**
- A** Embers that pass through deck board gaps will land on the ground, or on combustible materials stored under the deck, as shown during this IBHS test.
 - B** The near home noncombustible zone that surrounds the foundation should include a noncombustible area underneath the deck.
 - C** Vegetative debris in between deck board gaps will make this location even more vulnerable to ember accumulation.

RECOMMENDATIONS FOR YOUR DECK:

- 1** Combustible materials should not be stored beneath decks. This will effectively create a noncombustible zone under the entire footprint of the deck.
- 2** Routinely remove debris that accumulates in between deck board gaps and debris that can accumulate at the intersection between the deck and house.
- 3** If the deck is a non-fire-retardant treated softwood deck, consider removing and replacing deck boards within a few feet of the house. Be careful to match the deck board thickness.
- 4** When building new decks, select deck boards that comply with the California Building Code requirements. If using wood joists, cover the top and part of the sides with a foil-faced bitumen tape product.

that meet the requirements of an Ignition Resistant Material. However, as of this date, no other materials meet these requirements. The IWUIC allows an enclosed deck option that uses a horizontal construction attached to the bottom of the deck joists. This option should only be used with a solid surface deck. Using this option with deck boards (and the associated gaps), will cause moisture-related degradation problems (corrosion of fasteners and wood rot). Water from rain or melting snow will easily get into the enclosed space and will have a much harder time getting out.



FIREWISE USA™
RESIDENTS REDUCING WILDFIRE RISKS